

`dummy.gce`

Attributes

`mainvars: x`

Description

`dummy.gce` is what the name says: a dummy general element. It is required if there is a general variable (say, `v0`) in the user's circuit which is not associated with any general elements (GCE). In such a situation, `dummy.gce` should be connected to `v0`.

The same holds in AC analysis.