

pstprc_div2.gce

Attributes

mainvars: x1 x2 y

Description

pstprc_div2.gce can be used to obtain $y = x_1/x_2$ as a post-processing operation *only*.

If $y = x_1/x_2$ is required as a part of the circuit or system being simulated, `div_2` should be used instead.

In AC simulation, the relationship $y = x_1/x_2$ holds except that the variables are phasors in this case.