

`acos_deg.gce`

Attributes

mainvars: x y

Description

`acos_deg.gce` is used to get $y = \cos^{-1}(x)$ (in degrees).

AC behaviour is not implemented.