


rl_series.ece



Attributes

```
mainnodes: p n
outvar: i1=cur(p)_of_r1
stparms: i0sv=0
rparms: r=0.1 l=0.1
outvar_ac: i1ac=cur(p)_of_r1
```

Description

`rl_series.ece` is a series combination of a resistance `r` and an inductance `l` connected between nodes `p` and `n`. `i0sv` is used to specify the “start-up” value of `i1` in start-up simulation. The output variable `i1` is the branch current. The AC output variable `i1ac` is the AC branch current.