

intgrtr.gce

Attributes

mainvars: x y
stparams: y_sv=0

Description

intgrtr.gce gives $y = \int x \, dt$. The start-up parameter y_sv provides the starting value in start-up simulation.

In AC analysis, x and y are complex numbers that satisfy $\mathbf{X} = j\omega \mathbf{Y}$.