



ammeter_fb.ece

Attributes

mainnodes: p m

main_var: i_fb

Description

ammeter_fb.ece is an ammeter connected between nodes **p** and **m**. The current (from **p** to **m**) is made available as a general variable **i_fb** and can be used, for example, in control applications.

In AC, **i_fb** is an AC general variable (a phasor).