

intgrtr.gce

Attributes

mainvars: x y
stparams: y_sv=0

Description

intgrtr.gce gives $y = \int x dt$. The start-up parameter `y_sv` provides the starting value in start-up simulation.

In AC analysis, `x` and `y` are complex numbers that satisfy $x = j\omega y$.