



ammeter.ece

Attributes

mainnodes: p n

outvar: i1=brc_of_ammeter

outvar_ac: i1ac=brc_of_ammeter

Description

`ammeter.ece` is an ammeter connected between nodes `p` and `n`. The output variable `i1` gives the current through the ammeter from `p` to `n`. The AC output variable `i1ac` gives the AC current.