



rl.ece

Attributes

```

mainnodes: p n
outvar: i1=brc_of_rl1 v1=brv_of_rl1
stparms: i0sv=0
rparms: l=1 r=1
outvar_ac: i1ac=brc_of_rl1 v1ac=brv_of_rl1

```

Description

`rl.ece` is a series combination of a resistance r and an inductance l connected between nodes p and n . $i0sv$ is used to specify the “start-up” value of $i1$ in startup simulation. The output variables $i1$ and $v1$ are the branch current and branch voltage, respectively. The AC output variables $i1ac$ and $v1ac$ are the AC branch current and branch voltage, respectively.