


rt_ammeter_fb.ece



Attributes

mainnodes: p m
main_var: i_fb

Description

`rt_ammeter_fb.ece` is an ammeter connected between nodes `p` and `m`. The current (from `p` to `m`) is made available as a general variable `i_fb` and can be used, for example, in control applications.