

`set_rparm.gce`

Attributes

```
mainvars: x
sparms:
+   element_name=None
+   rparm_name=None
```

Description

`set_rparm.gce` is used to set a real parameter of an element. The name of the element is specified by the string parameter `element_name` and the name of the real parameter by `rparm_name`. The value of the concerned real parameter is set to be equal to the (current) value of the variable `x`.

In AC simulation, this element is ignored.