

filter_z0_p4.gce

Attributes

```
mainvars: x y
stparams: y_sv=0 y1_sv=0 y2_sv=0 y3_sv=0
rparams: a0=1 b0=1 b1=1 b2=1 b3=1 b4=1 f0=0.15915
```

Description

filter_z0_p4.gce satisfies the s -domain relationship,

$$y(s) = \frac{a_0}{b_0 + b_1 s + b_2 s^2 + b_3 s^3 + b_4 s^4} x(s).$$

f0 specifies the frequency value to be used for scaling of the filter coefficients, the default value being $1/2\pi$ Hz. The start-up parameters y_sv, y1_sv, y2_sv, and y3_sv provide the starting values for y , dy/dt , d^2y/dt^2 , and d^3y/dt^3 , respectively, in start-up simulation.

Note that there are two options for assigning the filter coefficients:

- (a) Enter coefficients for $\omega_c = 1$ rad/s and then enter the actual (desired) f_c in Hz.
- (b) Enter coefficients as required for the desired f_c but leave the default value of f0 unchanged.

In the first case, the coefficients will be changed internally; in the second case, they will be taken as assigned by the user.

In AC analysis, the above equation holds (with $s = j\omega$).