



## voltmeter.ece

### Attributes

mainnodes: p m

outvar: v1=brv\_of\_voltmeter

outvar\_ac: v1ac=brv\_of\_voltmeter

### Description

`voltmeter.ece` is a voltmeter connected between nodes `p` and `m`. The output variable `v1` gives the voltage across the voltmeter. The AC output variable `v1ac` gives the AC voltage.