dummy.xbe

Attributes

```
xbe name=dummy evaluate=yes
Jacobian: constant
input_vars:
output_vars: x
aux_vars:
iparms:
sparms:
rparms:
stparms:
igparms:
outparms:
```

Description

    `dummy.xbe` is a dummy element. It is required if there is a non-electrical variable (say, `x`) in the user's circuit which is not associated with any non-electrical element. In such a situation, `dummy.xbe` should be connected to `x`.